

SILICONE EDGE FABRIC - ENSAMBLE DE MARCO



1 Start by inserting one of the four provided angle bracket into the inner channel of the frames sides.



2 Next, find the corresponding top or bottom section and connect to form a gap-less 90 degree angle. Tighten both the bracket screws to secure the connection. Work around the rest of the frame corners connecting and securing the remaining top and bottom frame to the frame sides.



3 Once all 4 sides are complete you're ready to insert a silicone edge graphic and display!

